

Caution

Please read the following instructions carefully:

- Please follow our product installation and operation instructions.
- Always place the speaker on a smooth and stable surface.
- Please place the speaker on an open area for the best sound quality. Do not block the surroundings of the speaker.
- Do not push any objects into speaker vents or slots. Do not apply any great force on the speaker.
- Please keep the speaker at a room temperature environment. Do not place the speaker near any heat sources (such as radiators, heat registers, stoves, fire place, or direct sunlight). Do not place the speaker near any open flame source.
- Do not attempt to service the speaker by yourself. Always refer to the instructions by qualified service personnel.
- To avoid the risk of electrical hazard, do not expose this speaker to water or wet surface.

Welcome:

Thank you for purchasing this Divoom® product. TimeBox is a smart music gadget beyond your imagination. It is a Bluetooth speaker, a lamp, a digital palette, a thermometer, an alarm clock, all in one, which await for your exploration. To be inspired by sound and light, try this box of wonder and fun.

What's in the box?



1 pc of TimeBox

1 pc of User Manual




Buttons

1. HOLD: ON / OFF
PRESS: Battery Level
2. HOLD: Scan Station / Reject Call
PRESS: Play / Pause / Answer / End Call
Manual Alarm: Confirm Alarm
3. HOLD: Previous light effect
PRESS: Previous Song / Station
Manual Alarm: Switch Hour/Minute
4. HOLD: Next light effect
PRESS: Next Song / Station
Manual Alarm: Switch Hour / Minute
5. HOLD: Increase brightness
PRESS: Increase volume
Manual Alarm: Increase Time Value
6. HOLD: Decrease brightness
PRESS: Decrease volume
Manual Alarm: Decrease Time Value
7. HOLD: Manual Alarm
Press: Audio Source Switch (AUX / BT / Radio)
Manual Alarm: Exit
8. HOLD: Change Colors / Effects
PRESS: Snooze Alarm / Change Light Modes
Manual Alarm: Delete Alarm
9. Aux in
10. Power indicator light
11. Micro-USB charging port
12. Reset port
13. Aux out



Connecting and Using TimeBox

- 1) Download the Divoom TimeBox free App from App Store ® or Google Play ®
- 2) Please connect/pair with the "TimeBox" in the device's Settings / Bluetooth. For iOS, the process will require an extra pairing step (Please launch the TimeBox App, click the Magnify glass and select "TimeBox-Light" to pair).
- 3) You can use TimeBox App to do the following:
 - Automatically sync with clock and time zone on your mobile phone
 - Built-in FM Tuner allows you to listen to the radio and wake up alarm.
 - Stream music from your mobile device to the TimeBox via Bluetooth
 - Select songs from your iTunes library and adjust the speaker volume
 - Choose different drawing patterns from the Gallery or create your own in Design.
 - Set your custom sleep or wake up timers with preset scenery or your music and lighting
 - Customize the notification settings to alert a social media update



To switch your current connected device to another Bluetooth device, please follow these steps

1. Launch the TimeBox APP on the original Bluetooth device, then swipe and Delete the connected TimeBox on the APP's 'CONNECT' page
2. The LED display panel will flash the Bluetooth icon
3. Search and pair the TimeBox on the new mobile Device

How to setup an alarm manually without the mobile app

1. Hold the Audio Source Switch button


-
2. Click < or > to switch between hour and minute, then press + / - to change the time.
 3. Once completed, please press Play to confirm your setting.
- If you need to delete an alarm, please enter the manual alarm and press the snooze button to delete.
 - If you need to exit the manual alarm setting, please press the Audio Source Switch.

Hands-free

Press the Hands free button to pick up an incoming call.


OR

Press and hold the Hands free button for 2 seconds to reject an incoming call



Non-Bluetooth devices and FM Mode


Please connect the 3.5mm Auxiliary cable (provided) between the Timebox Aux-in port and the music source device. You can daisy-chain multiple TimeBox (in AUX mode) together via their Aux-out and Aux-in ports. The daisy-chain function does not support wireless connection, such as:Bluetooth.



For FM Radio, please click on the audio source button to switch to the FM Radio and use the station seeking buttons to switch station. For better signal strength, please place the Timebox in an open/semi-open area and you can attach a 3.5mm AUX cable as an external antenna for the TimeBox.

How to charge the speaker?

This speaker can be charge by most computer USB port and AC adaptor. The charging time may vary by the specification of the charging port/adaptor. A full charge will usually take 3~4 hours. To access the current battery level: Please press the power button, and the LED screen will display the current battery level.



How to record a voice message on the TimeBox?

You can record a voice message via the following methods: Using the TimeBox app, please select Voice Memo and start recording. Hold the Snooze / Lighting button until the record icon appear, then press the same button again after the recording. Once a voice message is recorded, a message icon will appear on the TimeBox screen, and you can press play button to playback the recorded message. The message will remain until it has been played, and power ON/OFF the Timebox will not delete this message. Once played, the message will be erased automatically.

LED display effect

Press the snooze/lighting button to switch between the different light effects.

Search and install “Divoom TimeBox” App on your mobile device to access the additional features on your TimeBox.



Features

- Built-in FM Tuner allows you to enjoy the excitement of your local radio station, and wake up to the local news broadcast
- Automatically sync with the clock and time zone on your mobile device, you don't have to adjust the time, ever.
- Over 30 preset sleep-aid programs for the best sleep experience, and always feel energetic when you wake up.
- Create a more detailed and vivid pixel art series with 121 Gem-style LED and 256 available colors.
- Enjoy the world-class audio through the fine-tuned speaker, and the built-in MIC and advance notification system.
- Available in different finishes, you can always find the perfect style that suit your modern home interior

Specifications:

Dimensions: 114L*55W*115.8H mm

Weight: 433g

Driver size: 3" full range

Output power: 5W

Frequency Response: 60-20000Hz

FM Frequency: 76-108MHZ

Signal-to-Noise Ratio: 78 dB

Playback Time: up to 10 hours

Battery Capacity: 2500mAh

Charge time: 3-3.5hours

Battery Voltage: 3.7V

Charging: Via USB cable,5V -1A


Bluetooth compliant: Bluetooth V4.0

Wireless range: Up to 10 meters

Declaration of conformity and CE mark

This device meets the requirements of the following EC directive R&TTE 1999/5/EG:

CE Directive 1999/5/EC of the European Parliament and of the Council of 9 March 1999 on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity

 The waste container symbol with the X through it on the device indicates that the device must be disposed of separately from normal domestic waste at an appropriate waste disposal facility at the end of its useful service life

Limited Warranty

1. If within 12 months of purchase this device or any part thereof is proven to be defective by reason of faulty workmanship or defects in materials, we will at our option repair or replace the same free of charge of labor or materials on condition that:
2. The original invoice or sales receipt with the date of purchase, or stamp from the dealer is presented together with the defective unit.
3. The warranty does not cover product failures which have been caused by use of accessories other than peripheral devices which are not DIVOOM branded original accessories intended for use with the product.
4. The warranty does not cover product failures caused by: Modification, repaired, and disassembled by any person who is not authorized by the manufacturer. Any defective unit or part shall become property of the manufacturer. The warranty does not cover any damage caused by misuse, drop, hit or neglect. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to

operate the equipment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.