


# **High Speed Drill**

6.5 mm (1/4") MODEL 6501



003002



# INSTRUCTION MANUAL

## **⚠ WARNING:**

For your personal safety, READ and UNDERSTAND before using. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

www.makitatools.com

# **SPECIFICATIONS**

Model		6501	
Consoition	Steel	6.5 mm (1/4")	
Capacities	Wood	9 mm (11/32")	
No load speed (RPM)		4,500/min.	
Overall length		206 mm (8-1/8")	
Net weight		0.9 kg (2.0 lbs)	

- Manufacturer reserves the right to change specifications without notice.
- Specifications may differ from country to country.

# **GENERAL SAFETY RULES**

USA002-2

(For All Tools)

## **↑ WARNING:**

**Read and understand all instructions.** Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

# SAVE THESE INSTRUCTIONS

#### Work Area

- Keep your work area clean and well lit.
   Cluttered benches and dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep bystanders, children, and visitors away while operating a power tool. Distractions can cause you to lose control.

### **Electrical Safety**

- Avoid body contact with grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is grounded.

- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord to carry the tools or pull the plug from an outlet. Keep cord away from heat, oil, sharp edges or moving parts. Replace damaged cords immediately. Damaged cords increase the risk of electric shock.
- When operating a power tool outside, use an outdoor extension cord marked "W-A" or "W". These cords are rated for outdoor use and reduce the risk of electric shock

## **Personal Safety**

- 9. Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use tool while tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating power tools may result in serious personal injury.
- 10. Dress properly. Do not wear loose clothing or jewelry. Contain long hair. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts.
- 11. Avoid accidental starting. Be sure switch is off before plugging in. Carrying tools with your finger on the switch or plugging in tools that have the switch on invites accidents.
- 12. Remove adjusting keys or wrenches before turning the tool on. A wrench or a key that is left attached to a rotating part of the tool may result in personal injury.
- 13. Do not overreach. Keep proper footing and balance at all times. Proper footing and balance enables better control of the tool in unexpected situations.
- 14. Use safety equipment. Always wear eye protection. Dust mask, non-skid safety shoes, hard hat, or hearing protection must be used for appropriate conditions. Ordinary eye or sun glasses are NOT eye protection.

#### **Tool Use and Care**

15. Use clamps or other practical way to secure and support the workpiece to a stable platform. Holding the work by hand or

- against your body is unstable and may lead to loss of control.
- 16. Do not force tool. Use the correct tool for your application. The correct tool will do the job better and safer at the rate for which it is designed.
- 17. Do not use tool if switch does not turn it on or off. Any tool that cannot be controlled with the switch is dangerous and must be repaired.
- 18. Disconnect the plug from the power source before making any adjustments, changing accessories, or storing the tool. Such preventive safety measures reduce the risk of starting the tool accidentally.
- 19. Store idle tools out of reach of children and other untrained persons. Tools are dangerous in the hands of untrained users.
- Maintain tools with care. Keep cutting tools sharp and clean. Properly maintained tools with sharp cutting edges are less likely to bind and are easier to control.
- 21. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the tools operation. If damaged, have the tool serviced before using. Many accidents are caused by poorly maintained tools.
- 22. Use only accessories that are recommended by the manufacturer for your model. Accessories that may be suitable for one tool, may become hazardous when used on another tool.

#### SERVICE

- 23. Tool service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel could result in a risk of injury.
- 24. When servicing a tool, use only identical replacement parts. Follow instructions in the Maintenance section of this manual. Use of unauthorized parts or failure to follow Maintenance instructions may create a risk of electric shock or injury.

**USE PROPER EXTENSION CORD:** Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause a drop in line voltage resulting in loss of power and overheating. Table 1 shows the correct size to use depending on cord length and nameplate ampere rating. If in doubt, use the next heavier gage. The smaller the gage number, the heavier the cord.

Table 1: Minimum gage for cord

Ampere Rating		Volts	Volts Total length of cord in feet			
		120 V	25 ft.	50 ft.	100 ft.	150 ft.
More Than	Not More Than			AWG		
0	6		18	16	16	14
6	10		18	16	14	12
10	12		16	16	14	12
12	16		14	12	Not Reco	mmended

# SPECIFIC SAFETY RULES

USB001-2

DO NOT let comfort or familiarity with product (gained from repeated use) replace strict adherence to drill safety rules. If you use this tool unsafely or incorrectly, you can suffer serious personal injury.

- Hold tool by insulated gripping surfaces when performing an operation where the cutting tools may contact hidden wiring or its own cord. Contact with a "live" wire will make exposed metal parts of the tool "live" and shock the operator.
- Always be sure you have a firm footing. Be sure no one is below when using the tool in high locations.
- 3. Hold the tool firmly.

- 4. Keep hands away from rotating parts.
- 5. Do not leave the tool running. Operate the tool only when hand-held.
- Do not touch the drill bit or the workpiece immediately after operation; they may be extremely hot and could burn your skin.
- Some material contains chemicals which may be toxic. Take caution to prevent dust inhalation and skin contact. Follow material supplier safety data.

# SAVE THESE INSTRUCTIONS

# **⚠ WARNING:**


MISUSE or failure to follow the safety rules stated in this instruction manual may cause serious personal injury.

SYMBOLS USD201-2

The followings show the symbols used for tool.

<b>V</b> volts	nno load speed
<b>A</b> amperes	☐Class II Construction
Hzhertz	/minrevolutions or reciprocation per
	minute

# FUNCTIONAL DESCRIPTION



Switch trigger
 Lock button

#### **⚠** CAUTION:

 Always be sure that the tool is switched off and unplugged before adjusting or checking function on the tool.

#### Switch action

### **↑** CAUTION:

- Before plugging in the tool, always check to see that the switch trigger actuates properly and returns to the "OFF" position when released.
- Switch can be locked in "ON" position for ease of operator comfort during extended use. Apply caution when locking tool in "ON" position and maintain firm grasp on tool.

To start the tool, simply pull the switch trigger. Release the switch trigger to stop.


For continuous operation, pull the switch trigger and then push in the lock button.

To stop the tool from the locked position, pull the switch trigger fully, then release it.

# **ASSEMBLY**

### **⚠** CAUTION:

 Always be sure that the tool is switched off and unplugged before carrying out any work on the tool.




1. Chuck key

# Installing or removing drill bit

To install the bit, place it in the chuck as far as it will go. Tighten the chuck by hand. Place the chuck key in each of the three holes and tighten clockwise. Be sure to tighten all three chuck holes evenly.

To remove the bit, turn the chuck key counterclockwise in just one hole, then loosen the chuck by hand.



- 1. Depth gauge
- 2. Washer
- 3. Clamp screw

## Depth gauge

Install the depth gauge on the tool with the clamp screw and washer. Adjust the depth gauge to the desired depth and tighten the clamp screw.

# **OPERATION**

## **Drilling operation**

## **Drilling in wood**

When drilling in wood, the best results are obtained with wood drills equipped with a guide screw. The guide screw makes drilling easier by pulling the bit into the workpiece.

## **Drilling in metal**

To prevent the bit from slipping when starting a hole, make an indentation with a center-punch and hammer at the point to be drilled. Place the point of the bit in the indentation and start drilling.

Use a cutting lubricant when drilling metals. The exceptions are iron and brass which should be drilled dry.

#### **△ CAUTION:**

- Pressing excessively on the tool will not speed up the drilling. In fact, this excessive pressure will only serve to damage the tip of your bit, decrease the tool performance and shorten the service life of the tool.
- There is a tremendous twisting force exerted on the tool/ bit at the time of hole breakthrough. Hold the tool firmly and exert care when the bit begins to break through the workpiece.
- Always secure small workpieces in a vise or similar holddown device.
- Avoid drilling in material that you suspect contains hidden nails or other things that may cause the bit to bind or break.

# **MAINTENANCE**

#### **↑** CAUTION:

 Always be sure that the tool is switched off and unplugged before attempting to perform inspection or maintenance.

To maintain product SAFETY and RELIABILITY, repairs, carbon brush inspection and replacement, any other maintenance or adjustment should be performed by Makita Authorized or Factory Service Centers, always using Makita replacement parts.

# **ACCESSORIES**

#### **⚠** CAUTION:

 These accessories or attachments are recommended for use with your Makita tool specified in this manual. The use of any other accessories or attachments might present a risk of injury to persons. Only use accessory or attachment for its stated purpose.

If you need any assistance for more details regarding these accessories, ask your local Makita service center.

- · Drill bits
- · Chuck key

First-Class
Postage
Required

Post Office will
not deliver
without proper
postage.

# Makita U.S.A., Inc. 14930 Northam Street

La Mirada, CA 90638-5753

Hdallaallaalldalalddaladdalallalall

# **MAIL THIS PORTION**

# Your answers to the following questions are appreciated.

1. This product was purchased	from:	3. How did you learn about th	is product:
1. This product was purchased Home Center Hardware/Lumber Store Tool Distributor Industrial Supply Construction Supply 2. Use of the product is intend Construction Trade Industrial Maintenance Home Maintenance Hobby Other ( )	Other ( )	3. How did you learn about th  Magazine From Dealer Newspaper Store Display Catalog 4. Most favored points are: Design Features Size Price Makita Brand	is product:  Radio Exhibition From Friend Previous Usage Other ( )  Repair Service Durability Power Other ( )
5. Any comments:		Mania Statia	
• • • • • • • • • • • • • • • • • • • •			
	. — . — . — . — . — . —		
DATE PURCHASED		MODEL NO.	
MONTH DAY	YEAR	SERIAL NO.	
		SENIAL NO.	
			STATUS SEX
INTL. LAST NAME / COMP	ANY NAME		Married Single M F
STREET ADRESS			
CITY			
SITY			
			AREA
STATE	ZIP CODE	PHONE	CODE
AGE: Under 1	9 20-29	30-39 40-49	50-60 Over 60
BE SURE TO COMPLETE TH	IE CUSTOMER'S PORTIC	N OF THIS FORM AND RETAIN	FOR YOUR RECORDS.

Facsimile No: (714) 522-8133

# **FACTORY SERVICE CENTERS**

#### 1-800-4-MAKITA

## RETAIN THIS PORTION FOR YOUR RECORDS

#### ALABAMA

2365 Pelham Parkway Pelham, AL 35124 (205) 620-1791

#### ADIZONA 3707 E. Broadway Rd., Ste. 6

Phoenix, AZ 85040 (602) 437-2850

#### ARKANSAS

Shackleford Shopping Center 240 South Shackleford Rd., Little Rock, AR 72211 (501) 224-5733

#### CALIFORNIA

41850 Christy St. Fremont, CA 94538-5107 (510) 657-9881 1421 N. Clovis Ave., Ste. 112

Fresno, CA 93727 (559) 252-5166

14930 Northam St. La Mirada, CA 90638-5753 (714) 522-8088

1970 Fulton Avenu Sacramento, CA 95825

1440 South "E" Street San Bernardino, CA 92408 (909) 885-1289

7674 Clairemont Mesa Blvd. San Diego, CA 92111 (858) 278-4471

1714 E.McFadden Ave., Unit M Santa Ana CA 92705 (714) 667-5066

Campbell, CA 95008-0501 (408) 379-0377

16735 Saticov St., Ste. 105 Van Nuys, CA 91406 (818) 782-2440

### COLOBADO

11839 E. 51st Ave Denver, CO 80239-2709 (303) 371-2850

## CONNECTICUT

508 Spring St. Windsor Locks, CT 06096 (860) 292-6405

#### FLORIDA

620 Douglas Ave. Suite 1302 Altamonte Springs, FL 32714 (407) 774-6000

750 Fast Sample Boad Pompano Beach, FL 33064 (954) 781-6333

Thompson Center Waters 5501 W. Waters Ave., Ste. 406 Tampa, FL 33634 (813) 886-8292

#### GEORGIA

4680 River Green Parkway Duluth, GA 30096-2566 (770) 476-8911

4510 Salt Lake Blvd., Suite A7 Honolulu, HI 96818 (808) 847-0038

1450 Feehanville Dr Mt. Prospect, IL 60056-6011 (847) 297-3100

8403 Michigan Road, Unit 1 Indianapolis, IN 46268 (317) 334-9980

#### KANSAS

8819 W. 95th St. Overland Park, KS 66212 (913) 642-1111

#### KENTUCKY

1215 S. Hurstbourne Parkway Louisville, KY 40222 (502) 326-3740

#### LOUGIANA 5626 Jefferson Hwy Harahan, LA 70123

(504) 733-4138

#### MARYLAND

7541 - 45 Ritchie Highway Glen Burnie, MD 21061 (410) 590-0160

#### MASSACHUSETTS 232 Providence Hwy Westwood, MA 02090 (617) 461-9754

MICHIGAN 37454 Ann Arbor Trail

Livonia, MI 48150 (313) 432-1012

#### MINNESOTA 6427 Penn Ave. South Richfield MN 55423

MISSOURI 9876 Watson Road St Louis MO 63126-2221

NEBRASKA 4129 S. 84th St. Omaha NF 68127 (402) 597-2925

NEVADA 3375 S. Decatur Blvd. Suites. 22 - 24 Las Vegas, NV 89102 (702) 368-4277

#### NEW JERSEY

251 Herrod Blvd. Dayton, NJ 08810-1539 (609) 655-1212

#### NEW MEXICO

5805 Menaul Blvd. NF Albuquerque, NM 87110

#### NEW YORK 4917 Genessee Street

Cheektowaga, NY 14225 (716) 685-9503

131-35 31st Ave Flushing, NY 11354 (718) 886-0971

## NORTH CAROLINA

3501-G S. Tryon St. Charlotte, NC 28217 (704) 527-0611

6253 E. Main St Columbus, OH 43213 (614) 860<sub>0</sub>0222

6379 Pearl Boad Parma Heights, OH 44130 (440) 843-7555

1617 E. Kemper Rd. Sharonville OH 45246 (513) 771-0788

#### OKLAHOMA

552 E. Memorial Road Oklahoma City, OK 73114 (405) 752-2655

#### OREGON 828 19th Avenue., N.W.

Portland OR 97209 (503) 222-1823

#### DENINGVI VANIA

Springwater Plaza 364 Wilmington W. Chester Pike Glen Mills PA 19342 (610) 459-4122

6200 Babcock Blvd Pittsburgh, PA 15237 (412) 366-6363

#### PUERTO RICO

200 Guayama St Hato Rey, PR 00917 (787) 250-8776

#### TENNESSEE 4655 Nolensville Rd

Nashville, TN 37211 (615) 331-9922

12801 Stemmons Fwy Ste 809 Farmers Branch, TX 75234 (972) 243-1150

12701 Directors Dr Stafford, TX 77477-3701 (281) 565-8665

3453 IH-35 North, Ste. 101 San Antonio, TX 78219 (210) 228-0676

145 E. 1300 S., Ste. 101 Salt Lake City, UT 84115 (801) 359-3410

#### VIRGINIA

5760 Northampton Blvd,. Ste Virginia Beach, VA 23455 (757) 460-0280

#### WASHINGTON 22220 84th Ave So Bldg A

Kent, WA 98032 (253) 395-8055

#### WISCONSIN Lincoln Plaza Shopping Ctr.

2245 S. 108th St. West Allis, WI (414) 541-4776

#### CUSTOMER'S RECORD

When you need service: Send complete tool (prepaid) to one of the Makita Factory Service	Date Purchased
	Dealer's Name & Address
Centers listed, or to an Authorized Makita Service Center. Be sure	
to attach a letter to the outside of the carton detailing the problem with your tool.	Model No.
	Serial No.

# WARNING

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- lead from lead-based paints,
- crystalline silica from bricks and cement and other masonry products, and
- arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

# MAKITA I IMITED ONE YEAR WARRANTY

# Warranty Policy

Every Makita tool is thoroughly inspected and tested before leaving the factory. It is warranted to be free of defects from workmanship and materials for the period of ONE YEAR from the date of original purchase. Should any trouble develop during this one-year period, return the COMPLETE tool, freight prepaid, to one of Makita's Factory or Authorized Service Centers. If inspection shows the trouble is caused by defective workmanship or material, Makita will repair (or at our option, replace) without charge.

This Warranty does not apply where:

- · repairs have been made or attempted by others:
- repairs are required because of normal wear and tear:
- the tool has been abused, misused or improperly maintained:
- alterations have been made to the tool.

IN NO EVENT SHALL MAKITA BE LIABLE FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES FROM THE SALE OR USE OF THE PRODUCT. THIS DISCLAIMER APPLIES BOTH DURING AND AFTER THE TERM OF THIS WARRANTY.

MAKITA DISCLAIMS LIABILITY FOR ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF "MERCHANTABILITY" AND "FITNESS FOR A SPECIFIC PURPOSE," AFTER THE ONE-YEAR TERM OF THIS WARRANTY.

This Warranty gives you specific legal rights, and you may also have other rights which vary form state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

# Makita Corporation

3-11-8, Sumiyoshi-cho, Anjo, Aichi 446-8502 Japan